

# Res-Up Feeders

1. Remove brine tank cover.
2. Attach bracket to Res-Up Feeder (plastic container) and position in brine tank next to brine well as shown in **Figure 1 on the front of this sheet.**
3. Drill  $\frac{1}{8}$ " hole in brine well cap for Feeder. Drill two  $\frac{1}{8}$ " holes in brine tank, under rim, for bracket and grommets.
4. Remove Feeder and fill to top with water so the filter stone tube and wick are immersed. Allow to soak for 15 minutes or more.
5. Empty container and pull tubing until stone is upright, and resting in bottom of stone well.
6. Insert free end of tube into brine well cap. This end of the tube must be below the bottom level of the Feeder.
7. Reinstall Feeder and bracket.
8. Fill plastic container with Res-Up<sup>®</sup> Cleaner to the "Fill Line" on label.
9. Replace cover on container and automatic feeding will occur within a few hours.
10. On S6306 Clear 1.0 oz there is no filter stone. Make sure knotted wick end is at bottom of container.

## Res-Up<sup>®</sup> Cleaner and Feeder Application Guide

APROX. RESIN BED SIZE	DELIVERY FEED	REGENERATION CYCLE (12 DAY CLOCK)				
		1 Cycle	2 Cycle	3 Cycle	4 Cycle	5 Cycle
$\frac{1}{2}$ cu. ft.	Light	Yellow	Yellow	Yellow	Yellow	Yellow
	Medium	Yellow	Yellow	Yellow	Yellow	Yellow
	Heavy	Yellow	Yellow	Yellow	Yellow	Yellow
$\frac{3}{4}$ cu. ft.	Light	Yellow	Yellow	Yellow	Yellow	Yellow
	Medium	Clear	Yellow	Yellow	Yellow	Yellow
	Heavy	Clear	Clear	Yellow	Yellow	Yellow
1 cu. ft.	Light	Clear	Yellow	Yellow	Yellow	Yellow
	Medium	Clear	Yellow	Yellow	Yellow	Yellow
	Heavy	Clear	Clear	Yellow	Yellow	Yellow

**Note:** Res-Up is not to be used with Gel Zeolite. In the event the resin bed is initially contaminated you may add quantities of Res-Up cleaner directly into the brine well to start the cleaning action immediately.

ORDER NUMBER	FEEDER SIZE	FEED COLOR CODE	AVERAGE DELIVERY PER DAY	UNIT CTN	CTN WEIGHT
S6304	3 Pints	Yellow Tubing	.40 oz 12.0 cc	12	5 Lbs.
S6305	3 Pints	Clear Tubing	1.00 oz 30.0 cc	12	5 Lbs.
T6001-04	1 Quart	Res-Up Cleaner		12	8 Lbs.
T6002-04	1 Gallon	Res-Up Cleaner		4	38 Lbs.

### Recommended Dosages:

For heavily fouled softener beds use 3-4 oz per cubic foot for initial cleanup. For preventive maintenance, use  $\frac{1}{2}$ -1 oz per cubic foot per regeneration.